

Seat Adjuster



Cobra Office Base

Assembly List

Base Plate



1 x Gas Strut



Spider



Kit includes:

- 1 x Seat Adjuster
- 1 x Gas Strut
- 1 x Base Plate
- 1 x Spider
- 5 x Wheels
- 4 x M8 Nyloc Nut
- 8 x M8x20 Button Head

Wheels



Assembly Instructions

1. First, place and secure base plate to seat adjuster using **4 of M8 Nyloc nuts** and **8 of M8x20 button heads**. Secure both parts together using the holes closest to the front of the base plate.



3. Turn the spider upside down and place on a hard surface. Push wheels axels into the holes in the spider.



2. Turn the spider and wheels over and insert gas strut into the large central hole in the spider and push hard. The gas strut will seat properly into the spider when first sat on.



4. Align hole in the bottom of the seat adjuster with the top of the gas strut and place the two parts together. Once again parts will seat properly first sat on.



Your Cobra Office base is now complete, the only thing left to do before you can enjoy your office seat is to attach to the base. There will be 4 M8x20 button heads on the bottom of your new Cobra Seat, if not please use the extra provided in this kit.

Note

When fitting take note of the front of the office seat mechanism matched with the front of your seat before bolting together.