



Fire Safety Stick Seat Mount Kit - Installation Guide

Tools Needed

- Socket wrench
- Torque wrench
- Allen key

What's Included

- Forged seat mount bracket for your vehicle
- 2x Fire Safety Stick clips with **M6 Nyloc Nuts**
- **2x Extended bolts, 2x Spacers and 2x Washers (only included with selected applications)**
- Fire Safety Stick Pro (50 or 100 second version)
- Bundle Upgrade (optional) includes all of the above plus a Safety Hammer (with plastic Safety Hammer holder and bolts), Safety Hammer bracket, 2x Bolts and 2x Nyloc Nuts

Fitting the Fire Safety Stick Clips to Your Forged Seat Mount Bracket



Scan this QR code to view Fire Safety Stick Clips being mounted

We would recommend fitting the two Fire Safety Stick clips to the seat mount bracket before fitting the bracket into the car.

Step 1. Attach Clips to Fire Safety Stick

Place the two clips provided onto the Fire Safety Stick. Position them evenly on the Fire Safety Stick for stable support.

Step 2. Mount Fire Safety Stick to Bracket

Place the Fire Safety Stick, with the clips already attached, onto the seat mount bracket.

Step 3. Secure With M6 Nuts

Thread the M6 nyloc nuts onto the bolts and tighten gently using a wrench. **Important:** Do not overtighten! Aim for approximately 10 Nm torque to avoid cracking the clip.

If you are fitting the Safety Hammer bracket to your Forged seat mount bracket, please attach the Safety Hammer bracket to your seat mount bracket using the 2 bolts and nyloc nuts supplied. The plastic Safety Hammer holder can then be bolted to the Safety Hammer bracket using the other bolts supplied.

Fitting the Forged Seat Mount Bracket Into Your Vehicle



Scan this QR code to view the Safety Hammer bracket being mounted

Step 1. Remove Seat Rail / Runner Bolts

Slide the seat as far back as possible, to access the seat runner bolts. Using a socket wrench, carefully remove the two front seat rail bolts. Please note that for some vehicles, it may be necessary to remove plastic covers to access the bolts.

Step 2. Position the Bracket

If your kit **includes** new bolts, washers, and spacers:

- Place the **spacer** on the seat rail mount (ref. 3)
- Place the **bracket** on top of the spacer
- Add the **washer** above the bracket (ref. 2)
- Insert the **new, longer bolt** provided (ref. 1)

If your kit **does not include** new bolts, washers, and spacers:

- Use your vehicle's **original equipment seat bolts**

Step 3. Tighten Bolts to the Correct Torque

Securely tighten all bolts using a torque wrench.

Recommended torque: 35–45 Nm (refer to your vehicle's manual for exact value).

Ensure the bracket is firmly in place and doesn't shift.

