



Fire Safety Stick Side Mount Kit - Installation Guide

Tools Needed

- Socket wrench
- Torque wrench
- Allen key

What's Included

- Forged side mount bracket
- 2x Fire Safety Stick clips with **M6 Nyloc Nuts**
- **2x Extended Side Mount Bolts**
- **2x Spacers**
- **4x Washers**
- Fire Safety Stick Pro (50 or 100 second version)
- Bundle Upgrade (optional) includes all of the above, plus Safety Hammer (with plastic Safety Hammer holder and bolts), Safety Hammer bracket, 2x Bolts and 2x Nyloc Nuts

Fitting the Fire Safety Stick Clips to Your Forged Side Mount Bracket



Scan this QR code to view the Fire Safety Stick Side Mount Kit being Installed

We would recommend fitting the two Fire Safety Stick clips to the side mount bracket before fitting the bracket into the car.

Step 1. Attach Clips to Fire Safety Stick

Place the two clips provided onto the Fire Safety Stick. Position them evenly on the Fire Safety Stick for stable support.

Step 2. Mount Fire Safety Stick to Bracket

Place the Fire Safety Stick, with the clips already attached, onto the side mount bracket.



Scan this QR code to view the Safety Hammer Side Mount Kit being installed

Step 3. Secure With M6 Nuts

Thread the M6 nyloc nuts onto the bolts and tighten gently using a wrench. **Important:** Do not overtighten! Aim for approximately 10 Nm torque to avoid cracking the clip.

If you are fitting the Safety Hammer bracket to your Forged seat mount bracket, please attach the Safety Hammer bracket to your side mount bracket using the 2 bolts and nyloc nuts supplied. The plastic Safety Hammer holder can then be bolted to the Safety Hammer bracket using the other bolts supplied.

Fitting the Forged Side Mount Bracket to Your Seat

Step 1. Remove Current Side Mount Bolts

Remove the bolts that are currently fixing your side mounts to your seats.

Step 2. Position the Bracket

Your kit includes **new extended side mount bolts, four washers, and two spacers:**

- Leave the side mounts in position
- Place a washer in front of an existing mounting hole
- Add a spacer in front of the washer
- Put the side mount bracket in position
- Add another washer in front of side mount bracket
- Insert the new, longer bolt provided

Step 3. Tighten Bolts to the Correct Torque

Securely tighten all bolts using a torque wrench. Recommended torque: 35–45 Nm (refer to your vehicle's manual for exact value). Ensure the bracket is firmly in place and doesn't shift.