



**PART NUMBER**

**PFF12-106 / PFF12-1106**

**DESCRIPTION**

**FRONT WISHBONE REAR BUSH**

**INSTALLATION GUIDE**

**Product description:**

This bush fits into the rear position of the front wishbone and incorporates additional anti-lift properties to lower the rear of wishbone by 10mm. It is designed to complement PFF12-101 that fits into the front position of the same arm.



**Contents (parts per pack):**

- 2 x Polyurethane bushes
- 2 x Zinc plated brackets
- 4 x Zinc plated bolts
- 4 x Zinc plated nyloc nuts
- 1 x Grease

*Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual. It is recommended that:*

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

*All fasteners must be tensioned to manufacturer's torque settings.*

**Fitting Instructions:**

1. Remove original rubber bush from the front wishbone of the car.
2. Apply some of the supplied grease to the bore of the bush and fit the bush onto the end of the wishbone with the text FRONT facing towards the front of the car.
3. Re-fit the wishbone to the car using the supplied bracket and bolt kit. Place washers under each bolt and washer.

Text **FRONT**  
towards front  
of car.

