



PART NUMBER
PFR5-411

DESCRIPTION
REAR RADIUS/LATERAL ARM BUSH

INSTALLATION GUIDE

Product description:

Polyurethane bush with plated outer shell and stainless steel sleeve.
The car uses 10 of these bushes but are sold in pairs.

Contents (parts per pack):

- 4 x bushes
- 2 x stainless steel sleeves
- 2 x outer shells
- 1 x grease

*Please read the complete fitting instructions and check package components before fitment.
These fitting instructions are to be used as a guide and in conjunction with workshop manual.
It is recommended that:*

- all work to be carried out by a licensed technician;
 - all safety precautions adhered to;
 - wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.*

Fitting Instructions:

1. Press out the original bush from either the arm, upright or sub frame making a note of the position of the outer shell allowing the correct installation position of the new outer shell.
2. Press in the new outer shell to the same position as the original as noted in instruction 1.
3. Push one polyurethane bush in to each side. Apply grease supplied to the bore of the bush and the outside of the stainless sleeve. Push the stainless sleeve through the bush.
4. Re assemble components onto car.

