

VERY IMPORTANT NOTE

This Revotec Cooling Kit has been engineered to provide perfect cooling for your TR8. However it is essential the other components of the cooling system are operating correctly.

The following must be checked:

1. The Radiator has a normal life expectancy of approx 8-9 Years after this time It should be thoroughly assessed and any signs of deterioration such as furring up internally or out of shape it is recommended it is replaced.
2. The Radiator fins Must be clear of all debris such as mud and leaves.
3. The system Must be filled with Correct Coolant.
4. The Water Pump and thermostat must be operating correctly.

Disconnect the battery terminal.

1. Drain the water system and remove the top and bottom hose
2. Remove the 2 upper radiator mountings.
3. Lift the radiator out of its lower locating holes and locate the lower brackets over the lower pins with the bracket studs pointing towards the front of the car, then lower the assembly back into place with the pins back in the locations on the chassis, this should hold the lower brackets in place tightly.
4. Locate the upper bracket on the upper radiator mounting pins with the bracket studs pointing towards the front of the car and clamp in place with the upper radiator mounts Fig.1.
5. Mount the 4 plastic brackets to the electronic fan and slide the assembly onto the front of the radiator, attach in place using the supplied M6 nuts and washers Fig.3 & Fig.4.
6. Mount the Electronic Fan Controller in the bottom hose and follow the EFC instructions for information on set-up.

Fig.1



Fig.2



Fig.4



Fig.3

