

Alpine A110

Stainless Steel Sports Lower Grille

Kit Contents: -

1. off Lower Grille



Lower Mesh Grille Fitting Instructions

<https://www.youtube.com/watch?v=pxCeQh4e58E>

1. Remove number plate and number plate plinth (**UK type number plates only**). (You will need to drill the 2 rivets out of the side holes as shown in fig 1 and unscrew the bolts as shown in fig 2).
2. Fit masking tape around the apertures to protect the paintwork while fitting.
3. Guide the one side of the grille into the aperture and gently push the grille into position making sure all the brackets clip behind the aperture (fig 3).
4. Using a thin screwdriver through the mesh lever all the brackets so they are tightly into position (fig 4).
5. Remove the tape and the grilles are now complete.

Fig 1



Fig 2



Fig 3



Fig 4



THANK YOU FOR CHOOSING A ZUNSPORT PRODUCT.