

BMW Z 3

Stainless Steel Sports Front Lower Grille

Kit Contents: -

- 1. off Lower Grille



Lower Mesh Grille Fitting Instructions

1. Remover number plate
2. The grille will be flat and needs to be curved to follow the vehicle line.
3. Remove number plate plinth from vehicle.
4. Offer grille to the lower aperture hook the 2 lower brackets over the bumper and backing plate. (If the brackets do not stay down it may be that they have been bent in transport, Just bend them so that they put a little pressure downwards and reinsert into the aperture)
5. Replace the number plate plinth.
6. Replace the Number plate.
7. Your grille assembly is now complete.

