

BMW F44 M235i xDrive Centre Grille **Set FITTING INSTRUCTIONS**

Kit Contents: -

- 1. off L/H Outer Centre Grille Piece
- 1. off R/H Outer Centre Grille Piece
- 1. off Centre Grille Piece
- 2. off M4 x 30 Pins
- 2 off Retaining Brackets



SCAN ME

<https://www.youtube.com/watch?v=MHXeFdxuwpU>

Centre Grille Piece Fitting Instructions:

1. Fit masking tape around the apertures to protect the paintwork while fitting.
2. Guide grille into aperture and centralise grille (Fig 1 & 2)
3. Then, keeping the grille central, tighten the retaining brackets on the grille (Fig 3, 4 & 5) **DO NOT OVERTIGHTEN**
4. Now remove masking tape and your grille is complete



THANK YOU FOR CHOOSING A ZUNSPORT PRODUCT.

Outer Centre Set Fitting Instructions:

1. Fit masking tape around the apertures to protect the paintwork while fitting.
2. Guide inner clip behind aperture, ensure that you engage the inner bracket first and centralise grille (Fig 1 & 2).
3. Then secure the clips on the grille by using a thin screwdriver through the mesh. (Fig 3, 4 & 5)
4. Now remove masking tape and your grille is complete (Fig 6)

