



## <u>BMW Z 4</u> <u>Stainless Steel Sports Front Lower Grille</u>

## Kit Contents: -

- 1. off Lower Grille
- 4. off Black Screws No.6 x <sup>3</sup>/<sub>4</sub>"



## Lower Mesh Grille Fitting Instructions

- 1. Fit Masking Tape to paintwork around and in the edges of the aperture to protect paint from accidental Scratches.
- 2. Locate the grille into the aperture putting the corners in first, and then allow the centre to push back into position and the centre clip to hook into position behind the existing parts.
- 3. Fit the 4 screws through the square washers into the existing backing plate. (Do not over tighten)
- 4. Your grille assembly is now complete.



