

BMW Z3

Stainless Steel Sports Top Grille Set

Kit Contents: -

- 1. off LH Grille
- 1. off RH Grille

**Mesh Grille Fitting Instructions**

1. Put masking tape on chrome surface where the brackets engage the existing grille to protect the outer plastic surface.
2. Locate the new mesh grilles into position and push into place through the existing grille.
3. Make sure the brackets have hooked firmly into place. (Open Bonnet to check the hooks have engaged)
4. Remove the masking tape and your grilles are complete.

