

BMW Z4

Stainless Steel Sports Top Grille Set

Kit Contents: -

- 1. off LH Grille
- 1. off RH Grille

**Mesh Grille Fitting Instructions**

1. Put masking tape on chrome surface where the brackets engage the existing grille to protect the outer plastic surface.
2. Hook the top wire bracket into position through the centre vane behind the existing grille
3. Fit the grille to the aperture and push the side brackets into place through the existing grille.
4. Make sure all of the brackets have hooked firmly into place. (If not you can lever the brackets into position with a screwdriver through the mesh, while keeping pressure on the front of the grille)
5. Remove the masking tape and your grilles are complete.

