

BMW M140i Stainless Steel Sports Lower Grille

Kit Contents: -

- 1. off Lower Grille
- 2. off Retaining Brackets
- 2. off M4 x 20mm Cap Screws



[YouTube Tutorial –](https://www.youtube.com/watch?v=vntOF1nuDOw)
<https://www.youtube.com/watch?v=vntOF1nuDOw>



Lower Mesh Grille Fitting Instructions

1. Fit masking tape around the apertures to protect the paintwork while fitting.
2. Offer the grille to aperture and guide the two retaining brackets through the existing aperture locating the bottom clips first (fig 1).
3. When the grille is in place, secure the upper clips behind the aperture using a long, thin screwdriver (fig 2).
4. Hold the grille in place and tighten the retaining brackets making sure the grille stays central in the aperture (use a screw driver through the mesh to hold the retaining brackets in place (fig 3).
5. Remove the tape and the grilles are now complete.



Fig 1



Fig 2



Fig 3

THANK YOU FOR CHOOSING A ZUNSPORT PRODUCT.