

BMW M2 Gen 1 (F87) Stainless Steel Sports Centre Grille

Kit Contents: -

1. off Centre Grille

3. off M3 Toggle Clamp

3. off M3 x 20mm Pan Head



Lower Mesh Grille Fitting Instructions

https://www.youtube.com/watch?v=SylVy6f5OHU

- 1. Fit masking tape around the apertures to protect the paintwork while fitting.
- 2. Fit the 3 toggle clamps through the grille (fig 1).
- 3. Offer the grille to the aperture and locate the toggle clamps through the centre holes as shown in (fig 2 & 3).
- 4. Keep pressure on grille and tighten the screws into the toggle clamps making sure the grille stays central in the aperture. (use a screwdriver through the mesh to hold the toggle clamps in place (fig 4, 5 & 6).
- 5. Remove the tape and the grilles are now complete.













