

BMW G42 M240I Centre Stainless Steel Grille Set

Kit Contents: -

- 1. off L/H Centre Grille
- 1. off R/H Centre Grille



YouTube Tutorial; <https://www.youtube.com/watch?v=tdHo6y9-0u8>

Centre Grille Set Fitting Instructions:

1. Fit masking tape around the apertures to protect the paintwork while fitting.
2. Guide the one side of the grille into the aperture and gently push the grille into position making sure all the brackets clip behind the aperture (Fig 1).
3. Using a thin screwdriver through the mesh lever all the brackets so they are tightly into position (Fig 2 & 3).
4. Remove the tape and the grilles are now complete (Fig 4).
5. Complete the same process on the other centre grille.

