

Mini Clubman JCW Stainless Steel Outer Grille Set

Kit Contents: -

- 1. off L/H Upper Outer Side Grille
- 1. off R/H Upper Outer Side Grille
- 1. off R/H Lower Outer Side Grille
- 1. off L/H Lower Outer Side Grille
- 1. off R/H Inner Outer Side Grille
- 1. off L/H Inner Outer Side Grille
- 4. off 1/2" Screws





YouTube Tutorial - https://www.youtube.com/watch?v=zG1Xd-FJE1A

Inner Outer Grilles Fitting Instructions -

- 1. Fit masking tape around the apertures to protect the paintwork while fitting
- 2. Locate the grilles into position, check they are central (Fig 1)
- 3. Check that the grille is positioned on the plastic aperture (fig 2) which will allow the screws to go through to secure the grille and create the pilot hole (fig 3).
- 4. Holding the grille in position, fasten the grille to the aperture using the screws provided, both on the upper and lower side of the grille, making sure the grille is tightly fixed into position (fig 3 & 4) (Do not over tighten screws).
- 5. The grille is now complete.









THANK YOU FOR CHOOSING A ZUNSPORT PRODUCT.

zun eport



Part No. ZBM95919 / ZBM95919B

SHEET 2 of 3 Issue 1 Feb 2023

Outer Grilles Fitting Instructions: Please fit outer grilles in this order

- 1. Fit masking tape around the apertures to protect the paintwork while fitting.
- 2. Offer the upper outer grille to aperture and gently push the grille into position making sure all the brackets clip behind the aperture (fig 1).
- 3. Using the open aperture underneath, use your hand to ensure upper grille clips are secure (fig 2).
- 4. Using a thin screwdriver through the mesh lever all the brackets so they are tightly into position (fig 3).
- 5. Repeat for both sides
- 6. Remove the tape and the grille is now complete (fig 4).











Part No. ZBM95919 / ZBM95919B

SHEET 3 of 3 Issue 1 Feb 2023

- 1. Fit masking tape around the apertures to protect the paintwork while fitting.
- 2. Offer the lower outer grille to aperture and gently push the grille into position making sure all the brackets clip behind the aperture (fig 1).
- 3. Using a thin screwdriver through the mesh lever all the brackets so they are tightly into position (fig 2).
- 4. Repeat for both upper and lower grille
- 5. Remove the tape and the grille is now complete (fig 3).







