

BMW E92 M3

Centre Stainless Steel Sports Grille

Kit Contents: -

- 1. off Lower Grille
- 2. off 3/4 Screws



[YouTube Tutorial; https://www.youtube.com/watch?v=UfqzGO5-LmI](https://www.youtube.com/watch?v=UfqzGO5-LmI)

Centre Mesh Grille Fitting Instructions:

1. Fit masking tape around the apertures to protect the paintwork while fitting.
2. Locate the grille into the aperture and centralise the grille in the aperture as shown in fig 1.
3. Secure the grille to the aperture using the two screws provided. Screw either side of the grille (fig 2 & 3). **DO NOT OVER TIGHTEN**
4. Remove the tape and the grille is now complete (fig 4).

