

BMW Z4 E89 Sdrive20i M Sport

Lower Stainless-Steel Grille

Kit Contents: -

- 1. off Lower Centre Grille
- 3. off M3 Toggle Clamp
- 3. off M3 x 35mm Pan Head



YouTube Tutorial; <https://www.youtube.com/watch?v=94MuMu2et7w>

Lower Mesh Grille Fitting Instructions:

- 1. Fit masking tape around the apertures to protect the paintwork while fitting.**
2. Guide the grille into the aperture, remove and then mark the fixing position using masking tape and pen (fig 1 & 2)
3. Offer the grille to the aperture (fig 3) and locate the toggle clamps through the centre holes ensuring it fits correctly where the markings are. **The left-hand and right-hand side fixing position is 3 diamonds up on the OEM grille (fig 4 & 5). The centre is 4 up.**
4. Once the grille is in place and central, keep pressure on grille and tighten the screws into the toggle clamps making sure the grille stays central in the aperture. (DO NOT OVER TIGHTEN) (use a screwdriver through the mesh to hold the toggle clamps in place (fig 6 & 7).
5. Remove the tape and the grille is now complete (fig 8).

