

# Bentley Continental Stainless Steel Lower Grille Kit

**Kit Contents: -**

- 1. off Centre Grille Lower
- 1. off Side Grille Lower LH
- 1. off Side Grille Lower RH

**Tools required: - (Not included in set)**

- Masking Tape
- Screw Drivers



**Grille Fitting Instructions**

1. Remove existing plastic grilles from apertures.
2. Clean Apertures
3. Place masking tape around the apertures to protect paint work. (Keep about 5mm away from the position at the front of the old grille)
4. Insert the centre grille as follows: -
  - a. Hook one side and the upper wire L shaped bracket into the aperture behind the back of the bumper keeping the grille at an angle so the other brackets do not engage.
  - b. Push the second side bracket and grille into position, so that grille spring bracket engages and clip around the back of the bumper. (Make sure the clips have hooked into place, if they are not clipped fully, you can lever them into place through the mesh with a small screwdriver, while putting pressure on the front of the mesh).
5. Insert Side Grilles as follows: -
  - a. Locate the outer clip first into the aperture.
  - b. Flex the grille slightly to allow the upper and inner brackets to pass into the aperture.
  - c. Checking that all of the clips are in position push the grilles back into place.
6. Remove Masking Tape.
7. Your grilles are complete.



