

# Citroen Relay MY14 Stainless Steel Upper Sports Grille

**Kit Contents: -**

1. off Upper Grille



**Upper Mesh Grille Fitting Instructions**

1. Fit masking tape around the apertures to protect the paintwork while fitting.
2. Offer the grille to aperture and gently push the grille into position making sure all the brackets clip behind the aperture.
3. Using a thin screwdriver through the mesh lever all the brackets so they are tightly into position (fig 1 & 2).
4. Once the grille is in the correct position fasten the grille to the existing aperture using the screws provided as shown in fig 3
5. Remove the tape and the grilles are now complete.

