

Ford Focus ST

Stainless Steel Sports Grille Mesh Lower

Kit Contents: -

- 1. off Mesh Grille
- 1. off LH Upper
- 1. off RH Upper
- 4. off No.6 x ¾” Screws



Tools Required

P2 Screwdriver

Grille Fitting Instructions

1. Fit masking tape around aperture to protect paint.
2. Locate the two small upper grilles into position, Holding them firmly in place and making sure they are even. Screw through the lower fixing U washers into the existing plastic. (Do not over tighten, just until the grilles are held down)
3. Locate the new lower grille into position, check that it is central.
4. Push the spring hooks through the existing grille.
5. Check that the hooks have engaged if not, put pressure on the front of the grille, lever the brackets behind the existing plastic grille with a flat screw driver until they lock into position.
6. The grille is now complete.

HOOKS THROUGH MESH

SCREW FIXINGS THROUGH MESH



MASKING TAPE