

Ford Mondeo TDCi ST 155 & ST 220 Stainless Steel Sports Grille Mesh Lower

Kit Contents: -

- 1. off Mesh Grille
- 4. off Allen Screws
- 4. off Nut Plates

Tools Required

- Allen Key
- Screw Driver



Grille Fitting Instructions

1. Fit masking tape around aperture to protect paint, 5mm from existing mesh.
2. Remove Finishing strip from base of lower grille if fitted.
3. Line up the new mesh grille keeping it as central as possible.
4. Fix the nut plates to the grille with the screws and feed them through the existing plastic grille so that they are in position behind the plastic. Using a screw driver turn the nut plate around until it is able to clamp behind the plastic vanes, and then tighten the Allen nut to clamp the part in place.
5. Remove the masking tape
6. The grille is now complete.

