

Part No. ZFR30608

zun/spoi

<u>Ford Focus ST</u> <u>Stainless Steel Upper Sports Grille</u>

Kit Contents: -

- 1. off LH Grille
- 1. off RH Grille
- 2. off $\frac{1}{2}$ " X No.6 screws



Mesh Grille Fitting Instructions

- 1) Open the bonnet
- 2) Align the grille to the vehicle, hooking the lower bracket through the existing grille vanes.
- 3) Rotate the grille upwards into position, making sure the lower brackets have engaged and are holding the grille in place
- 4) While holding the grille firmly in position screw through the top brackets of the mesh grille into the existing plastic grille.
- 5) Your grille is now complete.



