

Ford Focus ST Stainless Steel Sports Grille Mesh Lower

Kit Contents: -

- 1. off Lower Mesh Grille
- 1. off LH Upper
- 1. off RH Upper
- 4. off No.6 C/sk x 3/4" Screws



Tools Required

P2 Screwdriver

Grille Fitting Instructions

- 1. Fit masking tape around aperture to protect paint.
- 2. Locate the two small upper grilles into position, Holding them firmly in place and making sure they are even. Screw through the lower fixing U washers into the existing plastic. (Do not over tighten, just until the grilles are held down)
- 3. Locate the new lower grille into position, check that it is central.
- 4. Push the spring hooks through the existing grille.
- 5. Check that the hooks have engaged if not, put pressure on the front of the grille, lever the brackets behind the existing plastic grille with a flat screw driver until they lock into position.
- 6. The grille is now complete.



