

# Ford Focus ST

## Stainless Steel Sports Grille Mesh Lower

**Kit Contents: -**

- 1. off Lower Mesh Grille
- 4. off No.6 C/sk x 3/4" Screws

**Tools Required**

P2 Screwdriver



**Grille Fitting Instructions**

1. Fit masking tape around aperture to protect paint.
2. Locate the new lower grille into position, check that it is central.
3. Push the spring hooks through the existing grille.
4. Check that the clips have engaged if not, put pressure on the front of the grille, lever the brackets behind the existing plastic grille with a flat screw driver until they lock into position (Fig 1).
5. Screw the pins through the U brackets into existing plastic (Do not over tighten) (Fig 2).
6. The grille is now complete.

HOOKS THROUGH MESH

SCREW FIXINGS THROUGH MESH



Fig 1

Fig 2