

Ford Focus RS MK2 Stainless Steel Lower Sports Grille

Kit Contents: -

1. off Lower Grille



Lower Mesh Grille Fitting Instructions

- 1. Firstly start with removing the bumper from the vehicle.
- 2. After removing the bumper from the vehicle remove the fixing screws at the back of the grill and under the front (Fig 1).
- 3. Now carefully press the taps around the lower grill gently pulling it forward until it comes free from the bumper (Fig 2).
- 4. With the grill surround free from the bumper start to remove the clips holding the grill to the surround being careful not to snap the clips holding the grill down (Fig 3).
- 5. Now remove the Lower grill from the surround and replace it with the new replacement. Replace all the clips on the tabs and make sure it's secure.
- 6. With the grill now in place you can re-assemble the bumper and enjoy your fresh looking lower grill
- 7. If you require any more info please let me know.









