

Ford Transit MK8 Stainless Steel Lower Grille

Kit Contents: -

1 off Centre Grille



[YouTube Tutorial –
https://www.youtube.com/watch?v=goOv4SJVX-Y](https://www.youtube.com/watch?v=goOv4SJVX-Y)

Lower Mesh Grille Fitting Instructions

1. Fit masking tape around the apertures to protect the paintwork while fitting.
2. Carefully guide the grille into the aperture (Fig 1).
3. Using a screwdriver as shown in fig 2 push clips down making sure they locate behind the back aperture & grille is secure.
4. Remove the tape and the grilles are now complete.



Fig 1



Fig 2