

Ford Transit Connect Facelift Stainless Steel Sports Lower Grille

Kit Contents: -

1. off Upper Mesh Grille
4. off 3/4" Screws



YouTube Tutorial - <https://www.youtube.com/watch?v=haYEvJQwqMs>

Grille Fitting Instructions

1. Locate the grille into position, check that it is central whilst locating the brackets (Fig 1)
2. Now that the grille is in position check that all the brackets have engaged properly, you can do this by using a thin screwdriver through the mesh (fig 2 & 3).
3. Fasten the lower part of the grille to the existing aperture using screws provided making sure the grille is tightly fixed into position (fig 4) (Do not over tighten screws).
4. The grille is now complete.

