

Part No. ZFT12806 – Full Set Part No. ZFT7506 – Upper Grille Part No. ZFT12706 – Lower Grille

# FIAT GRANDE PUNTO – (Body Kit) Stainless Steel Sports Front Grille Kit

#### **Kit Contents: -**

# **ZFT12806**

1 off Upper Grille1 off Lower Grille

#### **ZFT7506**

1 off Upper Grille

#### **ZFT12706**

1 off Lower Grille



### **Tools Required:**

Small Pliers
Thin Flat Screwdriver

# **Upper Mesh Grille Fitting Instructions**

- 1. Remove the upper existing grille; this grille can be removed from the front by pulling from one side at a time. The old part can be kept for refitting later if required.
- 2. Place masking tape around the apertures to protect the paintwork while fitting the new grilles.
- 3. Offer the grilles to the apertures and locate the brackets into the existing slots on the bumper or lower grille.
- 4. When you are sure the grille is in the correct central position push the grilles into place until all of the brackets are fully engaged, use screwdriver if required.
- 5. Your grille assembly is now complete.









# Part No. ZFT12806 – Full Set Part No. ZFT7506 – Upper Grille Part No. ZFT12706 – Lower Grille

# **Lower Mesh Grille Fitting Instructions**





- 1. Remove the lower existing grille; this grille can be removed from the front by pulling from one side at a time. The old part can be kept for refitting later if required.
- 2. Place masking tape around the aperture to protect the paintwork while fitting the new grille.
- 3. Centralise the grille to the cavity and locate the bottom clips first over the original panel, push the grille into place to secure all of the clips.
- 4. The use of a screwdriver can be made to secure the clips if required.
- 5. Remove the masking tape and assembly is.

