

Citroen Relay/Fiat Ducato/Peugeot Boxer Gen3 Facelift Stainless Steel Lower Sports Grille

Kit Contents: -

1. off Lower Grille

2. off No 6 x ³/₄" Screws



YouTube Tutorial

https://www.youtube.com/watch?v=dFb-GIgWx-Q

200 200

Lower Mesh Grille Fitting Instructions

- 1. Fit masking tape around the apertures to protect the paintwork while fitting.
- 2. Offer the grille to aperture and gently push the grille into position making sure all the brackets clip behind the aperture (fig 1 & 2).
- 3. Using a thin screwdriver through the mesh lever all the brackets so they are tightly into position (fig 3).
- 4. Once grille is in position fasten grille to car using the small screw provided (Fig 4).
- 5. Remove the tape and the grilles are now complete.









