

Abarth 595

Air Vent Stainless Steel Grille Set

Kit Contents: -

- 1. off L/H Air Vent Grille
- 1. off R/H Air Vent Grille
- 2. off M3 Toggle Clamps
- 2. off M3 x 35mm Pan Head Screws



YouTube Tutorial; https://www.youtube.com/watch?v=6w-ItK_Va90

Air Vent Mesh Grille Fitting Instructions:

1. Fit masking tape around the apertures to protect the paintwork while fitting.
2. Ensure the correct grille is selected, you can check this by ensuring the pointed side of the grille fits flush in the aperture.
3. Guide the grille to the aperture and measure where the retaining bracket sits. Using a marker, mark up where on the OEM grille the retaining bracket will sit (fig 1 & 2)
4. Guide the grille into the aperture ensuring the retaining bracket fits into the OEM grille.
5. Tighten the retaining bracket until secure, DO NOT OVER TIGHTEN
6. Repeat on the opposite side.
7. Remove the tape and the grilles are now complete.



