

Abarth 595

Air Vent Stainless Steel Grille Set

Kit Contents: -

- 1. off L/H Air Vent Grille
- 1. off R/H Air Vent Grille
- 2. off M3 Toggle Clamps
- 2. off M3 x 25mm Pan Head Screws



YouTube Tutorial: <https://www.youtube.com/watch?v=gzT0z56xEwI>

Air Vent Mesh Grille Fitting Instructions:

1. Fit masking tape around the apertures to protect the paintwork while fitting.
 2. Guide the grille to the aperture and take note where the retaining bracket sits. On the OEM grille the retaining bracket will sit in the 4th hole down from the top, you can mark this up using tape (fig 1)
 3. Guide the grille into the aperture ensuring the retaining bracket fits into the OEM grille and remove tape (if necessary) (fig 2)
 4. Tighten the retaining bracket until secure, DO NOT OVER TIGHTEN (fig 3)
 5. Repeat on the opposite side.
- Remove the tape and the grilles are now complete.

