

## HONDA S 2000

# Stainless Steel Sports Grille Side Vent Kit

**Kit Contents: -**

- 1. off LH Grille
- 1. off RH Grille
- 4. off 15mm Screws



**Mesh Grille Fitting Instructions**

1. Put masking tape on painted surface of bumper where the Grilles are to be fitted
2. Locate each grille into position over the existing plastic insert.
3. Using the screw provided screw directly into the plastic insert through the square washers welded to the mesh (Do not over tighten the screws, just until they are held firmly against the plastic)
4. Remove the masking tape and the grille is complete.

