

Landrover Defender Stainless Steel Illuminated Front Grille



Kit Contents:

1 off - Front Grille

Illuminated Front Grille Fitting Instructions:

1. With a Phillips head screwdriver, remove the two screws holding the front right side light in place. Then remove the driver side (right hand side) side light as shown in Fig 1 (keep the screws)
2. Thread the new illuminated front grille harness through the vehicle as shown in Fig 2. Tip – use a wire coat hanger to help pull the harness through and out.
3. Disconnect the side light from the vehicle harness loom and reconnect the new illuminated front grille harness loom as shown in Fig 3.
4. Place the new illuminated front grille assembly back onto the bumper of the vehicle by following steps 1 and 2 in reverse.
5. Place the side light back and screw the part back into position. Using the two screws that were removed in step 6.
6. Check the side lights and the illuminated front grille are operational. If you have any issues, please contact our support team.



THANK YOU FOR CHOOSING A ZUNSPORT PRODUCT.