

Mercedes AMG E63s (W213) Stainless Steel Sports Outer Grille Set

Kit Contents: -

off Outer RH Side Grille
 off Outer LH Side Grille



YouTube Tutorial:

https://www.youtube.com/watch?v=QEX6O2RVPyY

Outer Side Mesh Grille Fitting Instructions

- 1. Fit masking tape just around the edges of the apertures to protect the paintwork while fitting.
- 2. 1st locate the outer edge of the grille into position and feed the outer edge bracket behind aperture as shown in fig 1.
- 3. Using a long screw driver push the clips down ensuring they locate behind the aperture fig 2 & 3.
- 4. Remove the tape and the grilles are now complete.







