

Mercedes AMG E63s (W213) Lower Stainless Steel Sports Grille

Kit Contents: -

1. off Centre Grille
2. off No6 x 2" Screws



YouTube Tutorial;

<https://www.youtube.com/watch?v=LDpSf-rNKeQ>



Centre Mesh Grille Fitting Instructions

1. Fit masking tape just around the edges of the apertures to protect the paintwork while fitting.
2. Carefully guide the Left hand Side of the grille into the aperture (fig 1).
3. Once the left hand side is located guide the right hand side slightly flexing the grille to allow it to locate behind the aperture.
4. Using a screwdriver as shown in fig 2 push clips down making sure they locate behind the back aperture & grille is secure.
5. Using the screws provided, screw the grille in to the plastic moulding to secure the grille into place (fig 3).
6. Remove the tape and the grilles are now complete.



Fig 1



Fig 2



Fig 3