

# Mercedes AMG C63 (W205) Lower Stainless Steel Sports Grille

## Kit Contents: -

- 1. off Centre Grille
- 3. off M3 Toggle Clamp
- 3. off M3 x 25mm Pan Head



## YouTube Tutorial:

<https://www.youtube.com/watch?v=HRwJgzkcpWw>

## Centre Mesh Grille Fitting Instructions

1. Fit masking tape just around the edges of the apertures to protect the paintwork while fitting.
2. Fit the toggle clamp through the grille (fig 1).
3. Offer the grille to the aperture and locate the toggle clamps through the centre holes as shown in (fig 2 & 3).
4. Keep pressure on grille and tighten the screws into the toggle clamps making sure the grille stays central in the aperture. (use a screwdriver through the mesh to hold the toggle clamps in place (fig 4, 5 & 6).
5. Remove the tape and the grilles are now complete.

