

# NISSAN NAVARA

## Stainless Steel Sports Upper Grille Kit

**Kit Contents: -**

- 1. off Centre Grille
- 1. off LH Side Grille
- 1. off RH Side Grille
- 5. off Screws  $\frac{3}{4}$ "

**Centre Mesh Grille Fitting Instructions**

1. Fit masking Tape over the existing chrome surround and badge 5mm from the inside edge.
2. Offer the new mesh grille centrally over the existing plastic grille & Badge.
3. Depress the spring brackets just enough to allow the grille to push backwards engaging the brackets.
4. Push the whole grille back until the part is fully against the existing plastic and the spring brackets have clipped into position.
5. Check all of the brackets have engaged. (If any of the brackets are not clipped over the plastic push them down with a long screwdriver while putting a little pressure on the front face of the grille)
6. Fit the screw into the position through the mesh and the U Shaped washer above the badge.
7. The centre grille is now complete.

**Side Mesh Grille Fitting Instructions LH & RH**

1. Fit masking Tape over the existing chrome surround 5mm from the inside edge Offer the Side mesh grilles into position over the existing plastic grille.
2. Hook in the two side brackets (If any of the brackets are not clipped over the plastic push them down with a long screwdriver while putting a little pressure on the front face of the grille)
3. Fix the 2 screw into position using the screws provided. (You can predrilled the holes if required using a max 2.0mm drill if required)
4. The side grilles are now complete.