

NISSAN NAVARA

Stainless Steel Sports Lower Grille Kit

Kit Contents: -

- 1. off Grille
- 4. off Spring Clips
- 2. off Screws 1½"



Centre Mesh Grille Fitting Instructions

1. Fit masking to protect paint approximately 5mm forward of the final grille position. If you put it too far in you can move it after the upper clips are fitted.
2. Fit the grille into position, then mark the upper bracket positions onto the masking tape, and then remove the grille.
3. Place the spring clips into position on the back edge of the aperture to correspond with the position marked for the upper brackets. Make sure they are fully pushed onto the plastic.
4. Fit the grille into position and push the upper brackets in between the spring clips and the plastic bumper so that the spring clips grip the brackets.
5. Screw the lower half of the grille to the bumper through the mesh and the U shaped washers. (Do not over tighten the screws as this will tear the plastic, Just tighten them up until the grille is held in position)
6. Remove the masking tape and your grille is complete.

