

Peugeot 208

Stainless Steel Sports Lower Grille

Kit Contents: -

- 1. off Lower Grille
- 2. off M3 Toggle Clamp
- 2. off M3 x 40mm Pan Head
- 4. off No6 x ¾ Screws



Lower Mesh Grille Fitting Instructions

1. Fit masking tape around the apertures to protect the paintwork while fitting (fig 1).
2. Offer the grille to aperture and mark the two centre diamonds on the masking tape shown (fig 2).
3. Remove the grille and fit the two toggle clamps through the grille (fig 3).
4. Offer the grille to the aperture and locate the toggle clamps through the centre holes as shown in (fig 4 & 5).
5. Keep pressure on grille and tighten the screws into the toggle clamps making sure the grille stays central in the aperture.(use a screw driver through the mesh to hold the toggle clamps in place (fig 6).
6. Once the grille is tightly in place and central, screw the four No6 x ¾ screws through the locating diamonds on the grille (fig 7 & 8).
7. Remove the tape and the grilles are now complete.



Fig 1



Fig 2

