

# Peugeot Boxer 3<sup>rd</sup> Generation PreFacelift Stainless Steel Sports Upper Grille

**Kit Contents: -**

1. off Upper Grille



**Upper Mesh Grille Fitting Instructions**

**YouTube Video – <https://www.youtube.com/watch?v=BgXxRjGQaEg>**

1. Fit masking tape around the apertures to protect the paintwork while fitting.
2. Offer the grille into the aperture ensuring the upper clips engage first as shown in fig 1.
3. Push grille into the aperture ensuring clips are locating into correct position.
4. Using a long screw driver push the clips down ensuring they locate behind the aperture. (fig 2)
5. Remove the tape and the grilles are now complete.




Fig 1




Fig 2