

Peugeot Expert / Citroen Dispatch / Vauxhall Vivaro - Upper Grille Stainless Steel Sports Grille

Kit Contents: -

1. off Upper Grille
2. off No6 x ¾ Screws



YouTube Tutorial; <https://www.youtube.com/watch?v=3gMxo-sWEGA>

Upper Mesh Grille Fitting Instructions

1. Fit masking tape just around the edges of the apertures to protect the paintwork while fitting.
2. Carefully guide the grille into the aperture (start from the right-hand side) making sure the is centralized in the aperture (fig 1).
3. Ensure all brackets have clipped behind the aperture). (You can use a long thin screwdriver to make sure they are clipped in position (fig 2).
4. Using the screws provided, secure the grille on each side (DO NOT OVERTIGHTEN) (fig 3).
5. Remove the tape and the grilles are now complete.



THANK YOU FOR CHOOSING A ZUNSPORT PRODUCT.