

Peugeot Expert / Citroen Dispatch / Vauxhall Vivaro - Lower Stainless-Steel Sports Grille

Kit Contents: -

1. off Lower Grille
2. off No6 x ¾ Screws



YouTube Tutorial: <https://www.youtube.com/watch?v=61YMqHaoedo>

Lower Mesh Grille Fitting Instructions

1. Fit masking tape just around the edges of the apertures to protect the paintwork while fitting.
2. **Starting with the left-hand side of the grille.** Carefully guide the grille into the aperture making sure it is centralized in the aperture (fig 1 & 2) and the brackets have clipped behind the aperture.
3. You can use a long thin screwdriver to make sure the brackets are clipped in position on the left-hand side of the grille (fig 2)
4. For the right-hand side of the grille, fix the grille into the aperture using the screws provided, at the upper and lower side of the grille).
5. Remove the tape and the grilles are now complete.

