

718 Boxster & Cayman 4.0 GTS

Stainless Steel Sports Side Vent Grille K

Kit Contents: -

- 2. off Side Vent Grille



Fitting Video - <https://www.youtube.com/watch?v=MFhaBO6iYLU>

Side Vent Mesh Grille Fitting Instructions

1. Fit masking tape around the apertures to protect the paintwork while fitting.
2. Carefully guide the grille so that the top bracket locates behind the aperture (Fig 1). Using a thin screwdriver, engage the clip behind the aperture (Fig 2).
3. Continue this with the lower brackets so that they have clipped behind the aperture and the grille is secured tightly into position (Fig 3 & 4).
4. Repeat for opposite side grille.
5. Remove the tape and the grilles are now complete.

