

Porsche Panamera 970 Facelift

Stainless Steel Sports Centre Grille

Kit Contents: -

- 1. off Centre Grille
- 1. off M4 x 30mm Cap Scr
- 1. off 407 Clip
- 2. off 2" Screws
- 2. off 2 1/4" Screws



YouTube Tutorial:

<https://www.youtube.com/watch?v=gmT3-3bJoaY>

Centre Mesh Grille Fitting Instructions



1. Fit masking tape just around the edges of the apertures to protect the paintwork while fitting.
2. Carefully guide the into the aperture making sure it is centralized (fig 1).
3. Using an Allen key through the mesh you can now secure the bracket to the existing plastic slat as shown in fig 5, ensure the grille is centralised. (You can use a screwdriver through the mesh to help hold the bracket in place whilst you are tightening the bracket).
4. Insert the 2 1/4" screws through the upper mesh diamonds and tighten down as shown in fig 3 (do not over tighten).
5. Insert the remaining 2" screws through the lower mesh diamonds and tighten down as shown in fig 4 (do not over tighten).
6. Remove the tape and the grilles are now complete.

