

Porsche 992.2 Carrera Base / T / S with Front Driving Camera Centre Stainless Steel Sports Grille FITTING INSTRUCTIONS

Kit Contents: -

1. off Centre Grille
2. off No6 x 2¼ Screws



YouTube Tutorial: <https://www.youtube.com/watch?v=7RCQN8HGfdu>

Centre Mesh Grille Fitting Instructions

If applicable remove number plate & plinth, you will need to trim the number plate holder

1. *Remove number plate & plinth if applicable, you will need to trim the number plate holder (fig 1).*
2. *Trim the tabs from the plinth (fig 2).*
3. Fit masking tape just around the edges of the apertures to protect the paintwork while fitting.
4. Carefully guide the grille into the aperture ensuring it is central in the aperture (fig 3).
5. Ensure the screws are secure through the diamond on the mesh (fig 4)
6. Using a screwdriver, secure the screws, one at either end of the grille (fig 5,6,7)
DO NOT OVERTIGHTEN.
7. Remove the tape and the grilles are now complete (fig 8).



