

Porsche Boxster & Boxster S Stainless Steel Sports Grille Kits

Kit Contents: -**ZPR 12296**

- 1. off Centre Grille
- 1. off LH Side Grille
- 1. off RH Side Grille

ZPR 17906

- 1. off LH Side Grille
- 1. off RH Side Grille

ZPR 17806

- 1. off Centre Grille

**Centre Mesh Grille Fitting Instructions**

1. Fit masking tape around the aperture to protect the paintwork while fitting.
2. Offer the new mesh grille to the Centre aperture
3. Flexing the grille a little, hook the two end brackets inside the aperture.
4. Now push the grille back until the lower grille bracket hooks behind the bumper inner edge.
5. Check all of the brackets have engaged fully. (If any of the brackets are not clipped over the plastic push them down with a long screwdriver while putting a little pressure on the front face of the grille)
6. Remove the tape and the centre grille is now complete.



LH & RH Side Mesh Grille Fitting Instructions

1. Fit masking tape around the apertures to protect the paintwork while fitting.
2. Offer the LH/RH mesh grilles to the aperture
3. Hook the outer brackets inside the aperture.
4. Push the grilles into position and hook the lower bracket into the aperture
5. Check all of the brackets have engaged fully. (If any of the brackets are not clipped over the plastic push them down with a long screwdriver while putting a little pressure on the front face of the grille)
6. Remove the tape and the grilles are now complete.

