

## Porsche Boxster 987 Stainless Steel Sports Grille Kit

## **Kit Contents: -**

off LH Side Grille
 off RH Side Grille



## **Side Mesh Grille Fitting Instructions**

- 1. Clean out the debris from the inside of the air intake.
- 2. Fit masking tape around the apertures to protect the paintwork while fitting.
- 3. Offer the LH/RH mesh grilles to the aperture
- 4. Hook the outer bracket inside the aperture.
- 5. Push the grilles into position and hook the other brackets into the aperture
- 6. Check all of the brackets have engaged fully. (If any of the brackets are not clipped behind the plastic push them down with a long screwdriver while putting a little pressure on the front face of the grille)
- 7. Remove the tape and the grilles are now complete.









