

Porsche Cayman – Manual Centre Stainless Steel Sports Grille Kit

Kit Contents: -

- 1. off Centre Grille
- 1. off LH Template
- 1. off RH Template



Centre Mesh Grille Fitting Instructions

1. Fit masking tape around the apertures to protect the paintwork while fitting.
2. Using Templates mark out the side fixing pin position. Keep the template at the top edge of the black insert. The two marks are the outside limits of the hole. (See Sketch #1.)
3. To get the distance of the hole from the black moulding measure 3.5mm out from the black insert this is the centre of the hole.(See Sketch #1.)
4. Drill 3mm holes as marked.
5. Clean debris.
6. Place the LH fixing pin into the hole; flex the grille so that the RH fixing pin locates into its hole.
7. Remove the tape and the grilles are now complete.

#Sketch 1

