

Porsche 996 Facelift Lower Stainless Steel Sports Centre Grille

Kit Contents: -

- 1 off Centre Grille
- 2 off 1 ½" Screw



Lower Mesh Grille Fitting Instructions

1. Masking tape Around all bumper appeture.
2. Offer grille to aperture then centralize the grille inside aperture.
3. Engage clips into position as shown in fig 1. (If there are any that have not hooked into position use a long screwdriver to put pressure on the top of the bracket while putting pressure on the front of the grille).
4. Fix into position using the screws provided through the centre fixing washers as shown in fig 2. (Do not over tighten)
5. Remove the tape.
6. The grille is now complete.



Fig 1



Fig 2